Customer Success Story: Flavors & Fragrances Manufacturing

Market Segment Life Sciences

Eaton brings customized filtration solution to major flavors and fragrances supplier

One of the more difficult flavors to filter is Vanilla Bourbon Tincture and Eaton was more than ready for the challenge.

Background

With subsidiaries in 32 countries, one of the world's largest flavors and fragrances manufacturers supports a variety of customers in the beverage, dairy, sweets, and other food processing industries as well as customers in the beauty, home care, perfumes and laundry products industries.

Recently wanting to increase productivity, the company teamed up with an engineering consulting firm to explore its options. The pair soon determined that replacing an old filtration system with a newer one could yield a wealth of positive results, including increased outputs, increased capacity, and improved efficiencies. A new filtration system would also bolster the company's desire to always employ sustainable business practices that includes water and energy usage reductions as well as significant cutbacks on the use of chemicals for cleaning.

Challenge

Before any changeover was made, however, the flavor and fragrance company wanted to make certain that its quality standards would not be compromised. To help ensure this, the company conducted a trial filtration test with a flavoring known as Vanilla Bourbon Tincture.

One of the more difficult flavors to filter, the Vanilla Bourbon Tincture had an initial turbidity of 141 NTU (Nephelometric Turbidity Units). The goal was to get the product clear with a turbidity of less than 3 NTU, and quickly process the targeted batch size, which was 2,600 kilograms (roughly 57,000 lbs.).

Eaton was more than ready forthe challenge.

Location: The Netherlands

Challenge:

To increase productivity while maintaining quality standards

Solution:

Eaton's BECO INTEGRA® PLATE 400 DC along with BECOPAD® filter sheets

Result:

Throughput speed tripled, quality standards achieved and commitment to sustainability uncompromised



Solution

Eaton presented its BECO INTEGRA PLATE 400 DC filtration system, which is completely enclosed, highly productive and safe to operate. Additional features include ideal flow distribution and product supply flow due to the configuration of the supply channels, and easy cleaning of the sanitary design of the filter elements.

In addition, four different types of filter media, including Eaton's popular, made of high-purity cellulose and environmentally friendly BECOPAD filter sheets, were tested to ensure that purification objectives were met as well as improved speed and output.

During tests, all four media achieved acceptable and comparable filtrate quality standards with turbidity levelswell below where they needed to be. Throughputs varied with the various media being tested.

Before a final decision could be made, though, Eaton discovered that a thin layer of impurities with a highly oily consistency were accumulating on the surface of the filter media. This indicated that most of the impurities were being removed by surface filtration, which was unacceptable. The impurities should be removed using the filter matrix and properly captured inside of the filter structure.

To remedy that, Eaton's BECOCEL[™] 100 pure cellulose filter aid was added as a body feed to see if that could help build a desirable permeable filter cake on top of the filter sheet. After various trials, Eaton soon discovered that a concentration of 0.18 percent BECOCEL 100 filter aid in combination with **BECOPAD 450 filter sheets** performed the best

Result

With the new filtration system in place in combination with the BECOPAD depth filter sheet and BECOCEL 100 filter additive, throughput speeds improved to roughly three times faster than before. In addition, their quality standards and sustainability objectives are being achieved with the Eaton BECO INTEGRA PLATE 400 DC filtration system.

Plant officials at the flavors and fragrances maker were so impressed with the results, they soon committed to purchasing two new Eaton filtration systems.

Due to the technical support and application knowledge that Eaton provided, the company has agreed to abandon the competitive filter media it had been using in favor of the Eaton BECOPAD 450 filter sheets used in the testing.



BECOPAD depth filter sheet



Enclosed BECO INTEGRA PLATE 400 DC plate and frame filter

North America 44 Apple Street Tinton Falls, NJ 07724 Toll Free: 800 656-3344 (North America only) Tel: +1 732 212-4700

Europe/Africa/Middle East

Auf der Heide 2 53947 Nettersheim, Germany Tel: +49 2486 809-0

Friedensstraße 41 68804 Altlußheim, Germany Tel: +49 6205 2094-0 An den Nahewiesen 24

55450 Langenlonsheim, Germany Tel: +49 6704 204-0

For more information, please email us at filtration@eaton.com Changning District, 200335 Shanghai, P.R. China or visit www.eaton.com/filtration © 2023 Eaton. All rights reserved. All trademarks

Greater China

Asia-Pacific

No. 7, Lane 280, Linhong Road

Tel: +86 21 5200-0099

100G Pasir Panjang Road

#07-08 Interlocal Centre

Singapore 118523

Tel: +65 6825-1668

and registered trademarks are the property of their respective owners. All information and recommenda-tions appearing in this brochure concerning the use of products described herein are based on tests believed to be reliable. However, it is the user's responsibility to determine the suitability for his own use of such products. Since the actual use by others is beyond our control, no guarantee, expressed or implied, is made by Eaton as to the effects of such use or the results to be obtained. Eaton assumes no liability arising out of the use by others of such products. Nor is the information herein to be construed as absolutely complete, since additional information may be necessary or desirable when particular or exceptional conditions or circumstances exist or because of applicable laws or government regulations.

US 12-2012

